

Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1) Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.
- **2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file
- **3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.
- **4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

http://www.adobe.com/support/techdocs/316508.html

Volume 63 Number 4 August 2007 Issue 302

MATERIALS LIST





MATERIAL LIST

	Part	Qty	Size	Material	
WIN	IDOW SEAT				
Α	TOP PANEL	1	³⁄4" x 24" x 63" *	Birch Plywood	
В	SEAT BOX SIDES	2	³ / ₄ " x 14 ¹ / ₂ " x 24"	Birch Plywood	
C	BACK	1	¾" x 8" x 61½" *	Birch Plywood	
D	FRONT CLEAT	1	³ / ₄ " x ³ / ₄ " x 61 ¹ / ₂ " *	Poplar	
Е	TOP RAIL	1	³4" x 3½" x 63" *	Poplar	*
F	EDGING	2	³ / ₄ " x ³ / ₄ " x 13 ¹ / ₄ "	Poplar	
G	BIN FRONT/BACK	2	¾" x 12" x 58¾" *	Birch Plywood	
Н	BIN SIDES	2	³ / ₄ " x 12" x 23 ¹ / ₄ "	Birch Plywood	
I	BIN BOTTOM	1	¾" x 21¾" x 58¾" *	Birch Plywood	
J	BOTTOM RAIL	1	%" x 4" x 61¼" *	Poplar	
K	BEADBOARD	1	3/8" x 83/4" x 611/4" *	Beadboard **]
DAY	BED .				
Α	TOP PANEL	1	¾" x 41" x 77"	Birch Plywood]
В	BOX SIDES	2	¾" x 15½" x 41"	Birch Plywood	
C	BACK	1	³⁄4" x 8" x 75½"	Birch Plywood]
D	FRONT CLEAT	1	3/4" x 3/4" x 77"	Poplar	
Е	TOP RAIL	1	¾" x 5" x 77"	Poplar	
F	FRONT PANEL	1	¾" x 14¾" x 75"	Birch Plywood	
G	BOTTOM RAIL	1	5⁄8" x 4" x 76½"	Poplar	1
Н	BEADBOARD	1	3/8" x 103/4" x 761/2"	Beadboard **	
					1
	1	1	l .	1	4

- * **NOTE:** Length of parts will vary based on size of opening. Size the Top Panel (A) ½" shorter than width of opening. Then adjust the length of other parts marked with an asterisk accordingly.
- ** **NOTE:** The beadboard used for this project can be the same as that used for the bedroom wainscoting (NewEnglandClassic.com). A suitable substitute is a PVC beadboard available at Home Depot that comes in 7½"-wide pieces. Butt the PVC pieces together edge-to-edge to fill the desired space.

HARDWARE:

- (115) #8 x 11/4" Fh Woodscrews
- (1) 4-pack of Bed Box Rollers (#71597) *
- (1) Duralink Trundle-Bed Frame ** (2) ½" Rare Earth Magnets (#30810), Cups (#31668), & Washers (#37474) *
- (2) 3/8"-dia. Dowels, 3/4" long (6) 1/4" Carriage Bolts, 1" long (6) 1/4" Nuts & Washers
- (4) Knobs
- * Items available from Rockler (800-279-4441, Rocker.com)
- ** Item available from Humble Abode (877-692-2633, HumbleAbode.com)

CUTTING DIAGRAM - WINDOW SEAT

A	В
	В
I	

3/4" x 48" x 96" Birch Plywood

	С		
	G		
	G		
н	Н		
		J	

3/4" x 48" x 96" Birch Plywood



CUTTING DIAGRAM - WINDOW SEAT

E

3/4" x 31/2" x 96" Poplar



3/4" x 51/2" x 96" Poplar

K	K	K	K	K	K	K	K	K	

1/4" x 71/4" x 96" Beadboard Planking



A A

 $\frac{3}{4}$ " x 48" x 96" Birch Plywood

В	В	
С		
F		

34" x 48" x 96" Birch Plywood




CUTTING DIAGRAM - DAYBED

E

3/4" x 51/2" x 96" Poplar

G D

34" x 51/2" x 96" Poplar



 $\frac{1}{4}$ " x $\frac{7}{4}$ " x $\frac{9}{6}$ " Beadboard Planking

Н	Н	Н	

1/4" x 71/4" x 96" Beadboard Planking

