



Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1)** Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.



- 2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file

- 3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.


- 4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

<http://www.adobe.com/support/techdocs/316508.html>


4 x 6 Frame




BACK VIEW




TOP VIEW



FRONT VIEW




SIDE VIEW





BACK VIEW


5 x 5 Frame




5 x 7 Frame




BACK VIEW




TOP VIEW



FRONT VIEW





SIDE VIEW




BACK VIEW

Triple 4 x 6 Frame




BACK VIEW




BACK VIEW



TOP VIEW



FRONT VIEW



END VIEW