


Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1) Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.
- **2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file
- **3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.
- **4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

http://www.adobe.com/support/techdocs/316508.html



When painting cabinet doors with raised panels, you need to paint the rails and stiles in a specific order so you keep a wet edge and maintain the proper look of the rails and stiles. Work quickly and carefully, making sure to keep your brush adequately filled and using just two or three brush strokes per application. Paint the center panel, rails, and stiles from the inside out in the order shown.