



Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1)** Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.

- 2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file

- 3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.

- 4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

<http://www.adobe.com/support/techdocs/316508.html>

MATERIALS LIST

A (2) Cabinet Top/ Bottom	$\frac{1}{2} \times 7 - 22$	M (8) Drawer Fronts/ Backs	$\frac{1}{2} \times 2\frac{7}{16} - 4 \frac{3}{8}$
B (2) Cabinet Sides	$\frac{1}{2} \times 7 - 23$	N (8) Drawer Sides	$\frac{1}{2} \times 2\frac{7}{16} - 6\frac{1}{4}$
C (1) Fixed Shelf	$\frac{1}{2} \times 6\frac{3}{4} - 22$	O (4) Plywood Bottoms	$\frac{1}{4} \times 3\frac{7}{8} - 6\frac{1}{4}$
D (1) Plywood Back	$\frac{1}{4} \times 22 - 22\frac{1}{2}$	P (1) Tissue Cover	$\frac{1}{2} \times 5\frac{3}{8} - 11\frac{3}{8}$
E (2) Vertical Part.	$\frac{1}{2} \times 6\frac{3}{4} - 6$	Q (2) Tissue Cover Stops	$\frac{1}{4} \times \frac{1}{4} - \frac{1}{2}$
F (2) Horizontal Part.	$\frac{1}{2} \times 5 - 6\frac{3}{4}$	R (4) Rails	$\frac{3}{4} \times 1\frac{3}{4} - 8\frac{1}{4}$
G (1) Top Cove Front	$\frac{1}{2} \times 2 - 23\frac{1}{2}$	S (4) Stiles	$\frac{3}{4} \times 1\frac{3}{4} - 16$
H (2) Top Cove Sides	$\frac{1}{2} \times 2 - 7\frac{1}{2}$	T (4) Filler Strips	$\frac{1}{4} \times \frac{1}{4} - 13$
I (1) Top Roundover Front	$\frac{1}{2} \times 2 - 24\frac{1}{4}$	U (4) Glass Stop	$\frac{1}{4} \times \frac{1}{4} - 64$
J (2) Top Roundover Sides	$\frac{1}{2} \times 2 - 7\frac{7}{8}$	V (2) Textured Glass Panels	$\frac{1}{8} \times 7\frac{5}{8} - 12\frac{7}{8}$
K (1) Bottom Roundover Front	$\frac{1}{2} \times 2 - 23\frac{1}{2}$	W (2) Adjustable Shelves	$\frac{1}{2} \times 5\frac{3}{4} - 21\frac{1}{4}$
L (2) Bottom Roundover Sides	$\frac{1}{2} \times 2 - 7\frac{1}{2}$	X (1) Cleat	$\frac{3}{4} \times 1\frac{1}{2} - 21\frac{1}{2}$

CUTTING DIAGRAM

$\frac{1}{2} \times 7\frac{1}{2} - 96"$



$\frac{1}{2} \times 7" - 96"$



$\frac{1}{2} \times 5\frac{1}{2} - 96"$



$\frac{3}{4} \times 5\frac{1}{2} - 96"$



Note: You will need about 120" of $\frac{1}{4} \times \frac{1}{4}$ " material for the Tissue Cover Stop Tabs (Q), Filler Strips (T), and Glass Stop (U)

$\frac{1}{4} \times 24" - 48"$ (PLYWOOD)

