

Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1) Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.
- **2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file
- **3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.
- **4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

http://www.adobe.com/support/techdocs/316508.html


WORKBENCH: ENTERTAINMENT CENTER

NUMBER 266


MATERIALS LIST

Α	(2)	Adjustable Shelves	34 x 21½ -31¼	ı	(1)	Top Panel	3/4 x 241/4 -39	Q	(1)	Upper Front Trim	3/4 x 3 -401/2
В	(2)	Edging Strips	¼ x ¾ -31¼	J	(1)	Case Back	1/4 x 291/2 -381/4	R	(2)	Upper Side Trim	34 x 3 -251/4
C	(2)	Side Panels	3/4 x 233/4 -693/4	K	(2)	Shelf Ends	34 x 5 -231/2	S	(1)	Baseboard	3/8 x 25/8 -120 rgh.
D	(4)	Spacer Blocks	3/4 x 21/4 -231/2	L	(1)	Shelf Back	34 x 5 -36	T	(2)	Bead Moldings	3/4 x 31/4 -64
Ε	(4)	Mounting Blocks	3/4 x 3 -231/2	M	(3)	Shelf Panels	34 x 23½ -37½	U	(2)	Shelf Edgings	3/4 x 11/2 -34 rgh.
F	(1)	Filler Strip	3/4 x 3/4 -371/2	N	(2)	Shelf Supports	34 x 3 -37½	V	(1)	Frt. Bkr. Board	3/4 x 41/2 -431/8
G	(1)	Top Stretcher	3/4 x 21/4 -39	0	(1)	Lwr. Front Trim	3/4 x 41/2 -401/2	W	(2)	Sd. Bkr. Boards	3/4 x 41/2-269/16
Н	(1)	Bottom Stretcher	¾ x 4½ -39	Ρ	(2)	Lwr. Side Trim	34 x 4½ -25¼	X	(1)	Crown Molding	3/8 x 35/8-144 rgh.

CUTTING DIAGRAM



1/4 x 48" - 48" Oak Plywood






EEEE

WORKBENCH. ENTERTAINMENT CENTER

NUMBER 266

3/4 x 48" - 96" Oak Plywood



		C			C		

3/4 x 48" - 96" Oak Plywood

M	M
M	

NUMBER 266

3/4 x 48" - 96" Oak Plywood

