

Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1) Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.
- **2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file
- **3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.
- **4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

http://www.adobe.com/support/techdocs/316508.html

June/July 2004 Number 3 Volume 60 Issue 283

MATERIALS LIST

MATERIALS & HARDWARE								
	Part	Qty.	Т	W	L	Material		
Α	Stretchers	4	11/2"	3½"	451/4"	Cedar 2x4s		
В	Rails	8	11/2"	31/2"	18¼"	Cedar 2x4s		
С	Corner Blocks	8	31/2"	31/2"	7"	Cedar 4x4s		
D	Rear Legs	2	31/2"	31/2"	56"	Cedar 4x4s		
Е	Front Legs	2	31/2"	31/2"	40"	Cedar 4x4s		
F	Middle Shelf Supports	2	11/2"	31/2"	18¼"	Cedar 2x4s		
G	Benchtop & Bottom Shelf	8	11/8"	5½"	48¼"	Composite Decking (Trex)		
Н	Middle Shelf	4	1"	51/2"	481/4"	Cedar Decking		
I	Side & Back Panel Slats	18	3/4"	41/4"	60" (rgh.)	Cedar		
J	Back Panel Cleat	1	3/4"	1½"	451/4"	Cedar		
K	Upper Shelf	1	1"	5½"	48¼"	Cedar Decking		
L	Сар	4	3/4"	41/4"	41/4"	Cedar		

CUTTING DIAGRAM

2 x 4 Cedar 8'

Α			A		
A			A		
В	В	В	В	F	
В	В	В	В	F	

4 x 4 Cedar 8'

E	D
E	D

4 x 4 Cedar 4'



2" x 6 " Cedar 6'

K

^{•(8)} $^3/_8$ " x 6" Lag Screws •(120) $^21/_2$ " Pocket-Hole Screws (coarse thread) •(60) #7 x $^15/_8$ " Stainless Steel Trimhead Screws

^{•(16) 2&}lt;sup>1</sup>/₂" Deck Screws (Galvanized) •(2) 3¹/₂"-dia. Cedar Finials

