



# Thank You!

---

**You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing**

- 1)** Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.
- 2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file
- 3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.
- 4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

<http://www.adobe.com/support/techdocs/316508.html>


## MATERIALS LIST




MATERIALS & HARDWARE						
	Part	Qty.	T	W	L	Material
A	Inner Leg Face	4	1/2"	5"	20"	Douglas Fir
B	Outer Leg Face	4	1/2"	5"	20"	Douglas Fir
C	Upper Leg Core	4	3/4"	4 3/8"	10 1/4"	Douglas Fir
D	Lower Leg Core	4	3/4"	5"	4 1/2"	Douglas Fir
E	Upper Rail (Front/Back)	2	1 1/2"	2 3/4"	38"	Douglas Fir
F	Lower Rail (Front/Back)	2	1 1/2"	4"	38"	Douglas Fir
G	Upper Rail (Ends)	2	1 1/2"	2 3/4"	14 3/4"	Douglas Fir
H	Lower Rail (Ends)	2	1 1/2"	4"	14 3/4"	Douglas Fir
I	Bottom Slat	8	3/4"	3 3/8"	14 1/8"	Douglas Fir
J	Bottom Cleat	2	3/4"	1 1/4"	28"	Douglas Fir
K	Siding (Ends)	6	3/4"	3 1/2"	14 3/4"	Douglas Fir
L	Siding (Front/Back)	6	3/4"	3 1/2"	29"	Douglas Fir
M	Plank (Rear)	1	3/4"	4 1/2"	42"	Douglas Fir
N	Plank (Front/Middle)	3	3/4"	4 7/8"	42"	Douglas Fir
O	Top Cleat	3	3/4"	1 1/2"	13 3/4"	Douglas Fir

- Titebond III Wood Glue
- (82) #8 x 1 1/4" Stainless Steel Fh Woodscrews
- (2) 3 1/2" Gate Hinges
- (32) 1 1/4" Brads
- (1) Tube OSI Silicone Sealer
- (1) 15" Chain for Lid
- Watco Penetrating Oil Finish

## CUTTING DIAGRAM




2 x 10 - 96", Douglas Fir



2 x 10 - 24", Douglas Fir

# CUTTING DIAGRAM



1 x 6 - 96, Douglas Fir