

# Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1) Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.
- **2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file
- **3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.
- **4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

http://www.adobe.com/support/techdocs/316508.html



## **Shaker-Style Vanity**

Issue 285 Volume 60

Number 5

September/October 2004

## **MATERIALS LIST**



	MATERIALS & HARDWARE													
	Part	Qty	T	W	L	Material			Part	Qty	T	W	L	Material
	Face Frame													
Α	Top/Bottom Rails	2	3/4"	1¾"	381/2"	Cherry		X	Bottoms	3	1⁄4"	1 <i>7</i> "	83/8"	Maple Plywood
В	End Stiles	2	3/4"	2¾"	29"	Cherry		Υ	Drawer Stops	6	3/4"	11/4"	11/2"	Cherry
С	Middle Stile	1	3/4"	1¼"	231/2"	Cherry			Doors					
D	Drawer Rails	2	3/4"	1"	11"	Cherry		Z	Door Rails	4	3/4"	3"	91/16"	Cherry
	Side Assemblies							AA	Door Stiles	4	3/4"	21/2"	21%"	Cherry
E	Front Side Stiles	2	3/4"	21/8"	29"	Cherry		BB	Door Panels	2	1/2"	8%"	16%"	Cherry
F	Rear Side Stiles	2	3/4"	21/2"	29"	Cherry		CC	Pegs	16	1⁄4"	n/a	7∕16"	Cherry Dowel
G	Upper Side Rails	2	3/4"	3"	16"	Cherry			Тор					
Н	Lower Side Rails	2	3/4"	31/2"	16"	Cherry		DD	Top Panel	1	1"	22"	44"	Cherry
ı	Center Stiles	2	3/4"	3"	191/2"	Cherry		EE	Back Apron	1	3/4"	5"	43"	Cherry
J	Side Panels	4	1/2"	<b>6</b> %"	191/2"	Cherry		FF	Side Aprons	2	3/4"	<b>2</b> ½"	201⁄4"	Cherry
K	Filler Strips	4	1/4"	1/2"	23/4"	Cherry		GG	Mounting Cleats	2	3/4"	1¼"	181/2"	Cherry
	Ply. Case Parts							НН	Mounting Cleat	1	3/4"	1¼"	1 <b>7</b> ½"	Cherry
L	Back Panel	1	3/4"	25"	41"	Cherry Plywood		II	Wall Cleat	1	1"	2"	35"	Scrap Stock
M	Bottom Panel	1	3/4"	19"	41"	Cherry Plywood		(1	5) #8 x 11/2" Rh Sh	neet /	Netal Scre	ws		_
N	Divider	1	3/4"	18¾"	23¾"	Cherry Plywood		1 (5	i) Screw-On Shake	r Kno	obs (Cherr	·y)*	2/	NLINE
	Drawer Guides								5) #8 x 1¼" Fh Wo 22) #8 x 2" Fh Wo	odscr	rews (tor k rews	(nobs)		Extras
0	Drawer Guide Mounts	3	3/4"	21/2"	181/2"	Cherry		(6	6) #8 x 11/2" Fh Wo	odsci	rews			Vanity
Р	Middle/Upper Guides	4	3/4"	1½"	181/2"	Cherry	(18) Nylon Stem Bumper Glides* 1½" Wrap-Around Hinges (2 pairs)* (2) Magnetic Catches for Inset Doors* (6) ¾6" I.D. x¾" O.D. Fender Washers (1) Lavatory Faucet (Kohler K-12183) (1) "Vessel-Style" Lavatory (Kohler K-2200)							
Q	Lower Guides	2	1/4"	1½"	181/2"	Cherry								
R	Spacers	2	3/4"	1¼"	231/2"	Cherry						benchMagazine.com		
S	Kicker	1	3/4"	13/4"	181/2"	Cherry								
	Drawers						(1) Vessel-Style Lavatory (Konier K-2200)							
T	Front/Back (Lower)	2	3/4"	<b>9</b> 3⁄8"	8%"	Cherry								
U	Fr./Bk. (Upper/Middle)	4	3/4"	47/8"	8%"	Cherry								
V	Sides (Lower)	2	1/2"	<b>9</b> 3/8"	1 <i>7</i> ½"	Maple		*Avo	ailable at <u>www.Rockle</u>	er.com				
W	Sides (Upper/Middle)	4	1/2"	47%"	17½"	Maple								

## WORKBENCH Shaker-Style Vanity

Issue 285 Volume 60

Number 5

September/October 2004

## **CUTTING DIAGRAM**


#### 34 x 5 - 96" CHERRY



#### 34 x 5 - 96" CHERRY



#### 34 x 5 - 96" CHERRY



#### 3/4 x 5 1/2 - 84" CHERRY

EE	FF	GG
EE	FF	HH

#### 34 x 6 - 96" CHERRY

Z	Z	Z	Z Z		В	В	
AA			AA		AA	AA	


#### 3/4 x 10 x 36" CHERRY

т	т	U	U
•	'	U	U

### **54** x 6 - 96" CHERRY (TWO BOARDS)

	DD	DD	
- 1			

## 1/2 x 71/4 - 84" CHERRY





Issue 285 Volume 60

ume 60 Number 5

September/October 2004

## **CUTTING DIAGRAM**


1/2 x 10 - 36" CHERRY

|--|

#### 1/2 x 10 x 72" HARD MAPLE

V	V	W	W	
		W	W	

### 34 x 48 x 96" CHERRY PLYWOOD



#### 1/4 x 48 x 96" CHERRY PLYWOOD

